

Allworx[®]

Phone Model 9202E User Guide

Updated May 21, 2014



Allworx® Phone Model 9202E User Guide



allworx®



©2014 Allworx Corp, a Windstream company. All rights reserved. No part of this publication may be reproduced, stored in a retrieval system, or transmitted, in any form or by any means, electronic, mechanical, photocopy, recording, or otherwise without the prior written permission of Allworx Corp.

Software in this product is Copyright 2014 Allworx Corp, a Windstream company, or its vendors. All rights are reserved. The software is protected by United States of America copyright laws and international treaty provisions applicable worldwide. Under such laws, the licensee is entitled to use the copy of the software incorporated with the instrument as intended in the operation of the product in which it is embedded. The software may not be copied, decompiled, reverse-engineered, disassembled, or otherwise reduced to human-perceivable form. This is not the sale of the software or any copy of the software; all right, title, ownership of the software remains with Allworx or its vendors.

Contents

Introduction	1
Setup	3
Connect the Phone	3
Adjust the Phone Angle	4
Volume Adjustment	5
Wall Mounting (Optional)	5
Wall Mounting Plate	5
Handset Retainer Clip	6
Overview	7
Buttons	8
Screen Icons	8
Feature Keys	8
Messages	8
Intercom	8
Conference	9
Transfer	9
Speaker	10
Mute/DND	10
Hold	11
My Allworx Manager	11
Operation	13
Place a Call	13
Receive a Call	13
End a Call	13
Headset	13
Directory Dialing	13
Redial a Number	14
Missed Calls	14



Presence 14

Ignore and Silence Soft Keys 15

Features 17

 Operator 17

 User / Resource Extensions 17

 Leave Another User a Voicemail 17

 Business Speed Dial 17

 Auto Attendant 17

 Overhead Pages 17

 Activate Door Relay 18

 Call Forwarding 18

 Paging Zones 18

 Conference Center 18

 Allworx Message Center 18

 Answer a Ringing Phone Using another Handset 19

 Park 19

 Announced Park 19

 Retrieve a Parked Call 19

Phone Configuration 21

 Personal Speed Dial 21

 Preferences 22

 Reboot the Phone 24

 Hot Desk Login 24

 Clear Call History 24

 Refresh Directory 25

 Network Profiles 25

Regulatory Notices 27

Abbreviations 29

1 Introduction

Unpack the Allworx phone and applicable accessories, identify each item in the checklist and inspect for missing items.

- **Allworx phone and base:** attach the base to the back of the phone. See “Adjust the Phone Angle” on page 4. for more information.
- **Handset with cord:** attach the cord to the jack on the back of the Allworx phone.
- **Phone Functions Reference Card:** slide the quick operating guide between the base and back of phone.

Additional equipment needed not included in the box:

- **Ethernet Cable:** connects the phone to the network
- **Power Supply:** provides power to the Allworx phone - rated 24VDC, 400 mA (or a network connection with Power over Ethernet).



2 Setup

2.1 Connect the Phone

Caution:	Do not connect the phone to an analog phone line. This may cause damage to the Allworx phone, which voids the warranty.
-----------------	---

To connect the phone:

Note:	Allworx 9202E handsets attached to the Allworx servers require using system software version 7.4 or higher. Do not attempt to install a 9202E phone on a server that is running a lower version of software.
--------------	--


1. Connect the cables to the jacks on the back of the phone.

Cable	Connections
Optional: Headset cord	Headset jack ()
Handset cord	Handset jack ()
Ethernet cable	Network jack () and Wall Ethernet jack Power over Ethernet (PoE): provides power to the phone after connecting the Ethernet cable.
Optional: Ethernet cable	Computer jack () and the computer.
Optional: Power Supply	Phone DC jack (). Allworx recommends using a surge protector. Only required if the Ethernet cable does not provide PoE

Back of Phone



2. Thread cables through the strain relief guide on the phone base.



3. View the initialization progress on the phone screen. A normal sequence includes:
 - Allworx Logo
 - Profile: <profile name> (depending upon the phone configuration)
 - Configuring Network
 - Starting network
 - Loading configuration files
 - Station Init complete

After successful startup, the phone displays a combination of the date, time, user presence, user name, and extension or the phone display may suggest assigning the handset to a user. If this occurs, follow the on screen directions. If the phone does not follow this sequence or displays an error, contact the Allworx Server Administrator.

2.2 Adjust the Phone Angle

The phone base angle adjusts for easier phone screen reading.

To adjust the phone base angle:

1. Unplug the phone from the PoE or the power supply. Remove the handset from the hook and lay the phone face down on a soft surface.
2. Hold the base with the fixed tabs facing the bottom of the phone. Select one of the three available positions to connect the base to the phone. The set of holes at the bottom of the phone provides the steepest angle.
3. Place the fixed tabs in the preferred holes on the back of the phone. Rotate the phone base upwards until the flexible tabs click into place.

To remove the base:

1. Remove the handset from the hook and lay the phone face down on a soft surface.
2. Press down on the flexible tabs and rotate the base towards the phone bottom until the fixed tabs easily lift out of the holes.

2.3 Volume Adjustment

The volume of the incoming ring, handset, speaker phone, and the headset is adjustable.

To adjust the incoming call volume:

1. Locate the phone volume bar. Do not lift the handset or turn on speaker phone.
2. Press the volume bar – (decrease) or + (increase) to adjust the incoming ring audio level. The phone plays the audio tone.

To adjust all other volumes:

1. Pick up the handset or turn on the speaker phone or headset. Locate the phone volume bar. The phone screen displays which audio path is being adjusted.
2. Press the volume bar to – (decrease) or + (increase) the audio level.

2.4 Wall Mounting (Optional)

Caution:	If using a standard telephone wall mount plate, DO NOT connect to the RJ-11 jack. This connection is for analog phones and may cause damage to the Allworx phone, which voids the warranty.
-----------------	---

2.4.1 Wall Mounting Plate

Mounting the Allworx phone on a wall requires a mounting plate that meets the TIA-570-B, Section standard and is available from a local telephone company or local retailer. The

mounting plate has studs that position the Allworx phone flush to the wall surface.



Leviton 4108W-0SP

Remove the Allworx phone base and mount the phone over the mounting plate studs. All power and RJ-45 cable connections should exit between the phone back and the wall, and then routed to the network connection and/or a power connection.

2.4.2 Handset Retainer Clip

The handset retainer clip prevents the handset from slipping out of the phone cradle while hanging on a wall. The Allworx phone ships with the adjustable handset retainer clip in the wall mount position on the phone cradle.

To adjust the retainer clip for desktop use (for easier handset removal/hang-up) insert a coin in the retainer clip slot and turn the coin clockwise, 180 degrees. To return the retainer clip to the wall mount position, insert a coin in the retainer clip slot and turn the coin counter-clockwise, 180 degrees.

3 Overview



In addition to English, the Allworx phone supports Canadian French and Castilian Spanish on the phone display when connected to Allworx servers using software 7.6.3.22 or higher. Contact the Allworx Server Administrator to configure the phone to display the preferred language; users cannot change the phone display language within the phone configuration menu. After making the change, the preferred language displays during the phone reboot.

3.1 Buttons

- **Keypad:** dial phone numbers or to enter PIN numbers/ passwords.
- **Navigation:** the up or down navigation arrows to move through the phone screen options. Use the center button to Select or Save settings.
- **Soft Key Selection:** select an option; located below the phone screen.

3.2 Screen Icons

Icon	Description
	New voicemails
	Missed calls
	On an active call

3.3 Feature Keys

3.3.1 Messages

The number of new messages displays on the LCD screen, and the MESSAGES button changes to red. next to the envelope icon ()

To retrieve messages:

1. Press the MESSAGES button.
2. Log in using the phone keypad, and follow the audio prompts.
3. Hang up to exit.

3.3.2 Intercom

The Allworx 9202E phone cannot initiate an intercom call. However the phone can receive Intercom calls. When another extensions places an Intercom call to the 9202E phone, it rings one of the phone lines. Users hear a distinctive Intercom beep, and then automatically answers the call.

3.3.3 Conference

The Allworx phone provides the ability to set up conferences between three parties (3-way conferences).

To connect a conference call:

1. Connect to the first person for the conference call. Press the CONF soft key.
2. Select the unused LINE button and dial the number of the second person for the conference call.
3. Press the CONF soft key. All three callers join in the conference. The Conf soft key changes to a dark In Conf indication.

One party may hang up to exit the conference; the remaining two parties continue to be connected.

To have a private conversation with one of the parties, split the conference:

- a. Use the phone UP / DOWN scroll soft keys to put on hold to select the line to put on hold.
- b. Press the HOLD button. The LINE button for that call on hold flashes green. Talk privately to the remaining party.
- c. To have the person re-join the conference, press the CONF soft key, then select the green flashing LINE button. The three-way conference becomes re-established.

3.3.4 Transfer

The TRANSFER button enables sending the active call to another number. After starting the transfer, the Transfer button is solid red, which indicates transferring a call to another extension using a Blind or an Attended Transfer. The transfer option works differently, depending on the Allworx server software version. Users have two transfer options:

- **Unannounced (Blind) Transfer:** user does not talk to the transfer recipient prior to transferring a call to that extension.
- **Announced (Attended) Transfer:** user talks to the transfer recipient prior to transferring a call to that extension.

To do a transfer:

1. Press the TRANSFER button.
2. Wait for the dial tone, and then dial the extension to transfer the call.
 - Unattended (Blind) Transfer: skip to step 3.
 - Attended (Announced) Transfer only: Talk to the recipient.
3. Hang up, press the TRANSFER button, or press the XFER soft key.

To transfer to voicemail:

1. Press the TRANSFER button, and then press the VMAIL soft key.
2. Dial the extension.
3. Hang up.

3.3.5 Speaker

Note:	The speaker phone does not work while using a headset. See “Headset ” on page 13. for more information on using headsets.
--------------	---

Press the SPEAKER button for hands-free use of the phone.

When using the handset, press the SPEAKER button. Then place the handset on hook. Take the handset off the hook to continue using it. When finished with the call, press the SPEAKER button to hang up.

3.3.6 Mute/DND

Mute a Call

During a call, press the MUTE/DND button to turn off the microphone in the handset, speaker phone, or headset. The MUTE/DND button is solid red while in use.

Do Not Disturb (DND)

When activating DND, the phone does not ring. All incoming calls follow the next step in the active call route. Users can send calls. The MUTE/DND is solid amber while in use. When not on a call, press the MUTE/DND button. Press the MUTE/DND button to de-activate the Do Not Disturb feature.

3.3.7 Hold

If the Allworx Server Administrator enables the Music on Hold feature for the call appearance, callers on hold will hear music.

To place a call on hold:

1. Press the HOLD button. The HOLD button becomes solid red. Place the handset on the hook. The LINE button for the held call blinks green until the user picks up the call again.
2. Pick up the handset to take the call off hold. If more than one call is on hold, the most recent call connects. The caller ID of the call picked up displays.
3. Pick up a different call on hold: press the flashing LINE button for that call or use the UP / DOWN scroll soft keys to display the call on the screen, and then pick up the handset.

If there is a call on hold and a new call comes in, lift the handset to answer the new call.

4. Hang up the handset when finished.

3.4 My Allworx Manager

My Allworx Manager provides access to the business directory, conference scheduling page, company phone list, distribution lists, phone features chart, and shared folders. Enter the My Allworx Manager address into a web browser (e.g. Internet Explorer).

The Allworx Server Administrator provides the address: <http://ServerLANAddress>, and then enter the log in username and password.

ServerLANAddress is the IP address or domain name of the Allworx server.



4 Operation

4.1 Place a Call

To place an outbound call, lift the handset or press the SPEAKER button. Dial the extension or press the SpDial soft key to automatically dial a programmed number. The phone configuration enables users to dial without lifting the handset or pressing a button. Dialing automatically activates the speaker phone or headset.

4.2 Receive a Call

For incoming calls, the audible indicator rings and a Call Appearance flashes, unless configured otherwise. Lift the handset, press the SPEAKER button, or press the flashing Call Appearance to answer the call.

4.3 End a Call

- Place the receiver on the hook. If using the speaker phone or headset, press the SPEAKER button.
- Press another Call Appearance. If a second incoming call is on another Call Appearance, pressing that Call Appearance ends the current call and answers the incoming call (unless the phone configuration enables auto on hold).

4.4 Headset

Press the SPEAKER button to activate the headset, and then press the SPEAKER button again to disconnect the call.

4.5 Directory Dialing

1. Press the UP / DOWN scroll soft keys to view a list of all User Extensions, System Extensions, and Speed Dial numbers by Name or Description.

2. Use the UP / DOWN scroll soft keys to highlight the name (or description) and extension or press the keypad to jump to a specific alphabetic section of the directory. Press SELECT  to dial the number.

4.6 Redial a Number

1. Press the REDIAL soft key on the phone display screen.
2. Press the CALLS softkey. Use the UP / DOWN scroll softkeys to highlight the call in the display. Press SELECT .

4.7 Missed Calls

After a missed call, a message displays on the phone screen next to the phone icon ().

To see the details of the missed calls:

1. Press the CALLS soft key, and then press the UP / DOWN scroll soft keys to view the missed calls.
2. Press the DETAIL soft key to view the date and time of the missed calls. Press SELECT  to call the number, if it is available.

4.8 Presence

The Presence setting identifies which call route the incoming call uses based on the extension availability. The Presence setting options include In Office, At a Meeting, On Vacation, On Business Trip, At Home, Away, and Busy.

1. Press and hold the MUTE/DND button.
2. Press the UP / DOWN scroll soft keys to view the presence states.
3. Press SELECT  to change the presence. The Presence setting changes, the default LCD screen displays, and all inbound calls follows the call route for this presence state. The MUTE/DND button flashes amber to indicate a presence setting other than "In Office".

4.9 Ignore and Silence Soft Keys

When a call is ringing, the SILENCE and IGNORE soft key options display on the phone screen.

- **IGNORE:** stops the audible ringing and the LINE button continues to flash until the user answers the call or the caller hangs up.
- **SILENCE:** stops the audible ringing, the phone screen displays the incoming call information, and the LINE button continues to flash until the user answers the call or the caller hangs up.



5 Features

The dialed-digits listed are system defaults, actual dialed-digits may vary. Check the phone functions tab of the My Allworx Manager page or contact the Allworx Server Administrator for the actual dialed-digits.

5.1 Operator

Dial (or transferring to) 0 to initiate a call to the company operator.

5.2 User / Resource Extensions

Dial any extension between 100 – 299 (three-digit mode) or 1000 – 2999 (four-digit mode) to connect a call to another user or to a call route (set up by the System Administrator).

5.3 Leave Another User a Voicemail

Dial 3 + extension to connect to another user's voicemail.

5.4 Business Speed Dial

The System Administrator specifies extensions 350 – 399 or 34000 – 34999 to ring specific numbers.

5.5 Auto Attendant

Dial extension 400 or 431 for the default Auto Attendant or extension 431 - 439 for a specific Auto Attendant.

5.6 Overhead Pages

Overhead paging is a third party plug-in. For systems configured and connected to an Overhead Paging system, access by dialing extension 402. Once activated, users can make an announcement through the intercom of each handset or to the overhead paging system.

5.7 Activate Door Relay

Dial extension 403 to activate a Door Relay, if connected and configured.

5.8 Call Forwarding

Forward incoming calls to another extension by dialing 45 + the extension. Disable Call Forwarding by dialing dial extension 450.

5.9 Paging Zones

Dialing 46# (# is a Paging Zone number, 0 through 9) to broadcast audio to members of the Paging Zone (setup by the Allworx Server Administrator).

5.10 Conference Center

Dial 408 to access the optional Conference Center feature. Refer to the Allworx Server User Guide.

5.11 Allworx Message Center

Press the MESSAGES button to access the Audio Message Center.

Users can also access the Audio Message Center by dialing 6 + the extension from any phone or from the company Auto Attendant. In the Message Center, users can:

- Listen to new or saved voicemails.
- Send a message to another user.
- Change presence setting.
- Change name recording.
- Manage message greetings.
- Change PIN.
- Set up one or more Presence-based inboxes to prevent callers from leaving messages.

5.12 Answer a Ringing Phone Using another Handset

To answer another ringing phone, dial 7 + the phone extension.

5.13 Park

Press the PARK soft key to park a call. The Allworx Server Administrator defines the maximum wait time of parked call and the subsequent routing.

5.13.1 Announced Park

Note:	Do not do a Blind Transfer to 700, this disconnects the call.
--------------	---

To Park a call using Attended Transfer:

1. Press the Transfer button.
2. Dial extension 700¹ and wait for the call to connect.
3. The Attended Transfer announces the Parking Orbit extension.
4. Hang up. The system parks the call in the announced location.

5.13.2 Retrieve a Parked Call

Dial the parking extension.

1. Digits may vary. Check the phone functions tab of the My Allworx Manager page or contact the Allworx Server Administrator.



6 Phone Configuration

Select the CONFIG soft key to view the following options:

Personal Speed Dial	Hot Desk Login	Network Profiles*
Preferences	Clear Call History	Current Status/Info*
Reboot Phone	Network Settings*	

* Indicates the option is only available to the Allworx Server Administrator.

Note:	Check with the Allworx Administrator before making changes.
--------------	---

6.1 Personal Speed Dial

To setup a Personal Speed Dial:

1. Press the CONFIG soft key. A menu displays on the phone LCD screen. Locate the Personal Speed Dial option and press SELECT .
2. Use the UP / DOWN scroll soft keys to choose a speed dial number, press SELECT .
3. Use the keypad to enter the phone number or extension, press SELECT .
 - The DOWN soft key acts as a backspace.
 - To add a one-second pause to the dialed number to wait for auto answer systems to prompt for additional dialing, press the PAUSE soft key (if one displays) or the HOLD button to add a one-second pause to the dialed number. Add enter multiple pauses, as necessary.
4. Use the keypad to enter a name for the speed dial, and then press SELECT . The '#' key puts a space between characters. The DOWN soft key acts as a backspace.

To use a Personal Speed Dial

1. Pick up a line, and press the SPDIAL soft key.
2. Enter the speed dial number. This places a call to the speed dial extension.

6.2 Preferences

1. Press the CONFIG soft key button. Press the DOWN scroll soft key to select Preferences. Press SELECT .
2. Select from the following list using the UP / DOWN scroll soft keys to make the changes:

Preference Setting	Description	Options
LCD Settings	Adjust the LCD display contrast and brightness settings.	Use the Volume bar or Up / Down scroll soft keys arrows.
Call History Size	Adjust the number of calls kept in the History.	0 to 99 (Default: 99)
Clock Mode	Display the time mode on the LCD Screen.	<ul style="list-style-type: none"> • Off • 12 Hour • 24 Hour
Hold Reminder Mode	Set the hold reminder functionality.	<ul style="list-style-type: none"> • No Reminder • On Hook • Timer • On Hook and Timer
Redial Memory	Store the last number dialed in the phone.	<ul style="list-style-type: none"> • Until reboot • 1 minute • 10 minutes • 1 hour
Audible Dialing	Hear tones when pressing a key.	<ul style="list-style-type: none"> • Enabled • Disabled
Call Timer Display	Display the length of a phone call.	<ul style="list-style-type: none"> • Enabled • Disabled
Intercom Auto Answer	Automatically answer an incoming intercom call using Intercom/Speaker phone.	<ul style="list-style-type: none"> • Enabled • Disabled
On Hook Dialing	Enable speaker mode when pressing a number on the keypad without pressing the SPEAKER button first.	<ul style="list-style-type: none"> • Enabled • Disabled
Visual Ringing	Enable the phone visual ring indicator to flash red for an incoming call.	<ul style="list-style-type: none"> • Enabled • Disabled
Paging Enable Mode	Enable the phone to receive pages.	<ul style="list-style-type: none"> • Never • Always • On Hook
Off Hook Answer Mode	Answer incoming calls when taking the phone off the hook.	<ul style="list-style-type: none"> • Off Hook Will Answer • Select to Answer
Off Hook Ringing	Enable the phone to ring when receiving a new call while in use.	<ul style="list-style-type: none"> • Enabled • Disabled
Auto on Hold	Place the current call on hold automatically when answering an incoming call.	<ul style="list-style-type: none"> • Enabled • Disabled

Preference Setting	Description	Options
Auto Retrieve Calls	Retrieve the on hold call automatically when taking handset off call.	<ul style="list-style-type: none"> • Enabled • Disabled
Missed Call Tracking	Track missed call appearances.	<ul style="list-style-type: none"> • Enabled • Disabled
Parking Orbit Pop-ups	Display the Parking Orbit after parking the call.	<ul style="list-style-type: none"> • Popup Disabled • Popup Enabled
Hold Button Operation	Set the HOLD button function.	<ul style="list-style-type: none"> • Hold then Park • Park then Hold • Hold Calls Park Lines
Force Auto Answer	Answer incoming calls automatically.	<ul style="list-style-type: none"> • Normal Operation • Auto Answer On
Sidetone Disable	Enable turning off the handset or headset microphone feedback to the speaker.	<ul style="list-style-type: none"> • Normal Operation • Handset Disabled • Headset Disabled • Both Disabled
Call Assistant CLID	Display the call information in Call Assistant and applications using the Allworx TSP driver.	<ul style="list-style-type: none"> • Calling Party Info • DNIS Information
Emergency Caller ID	Display the Caller ID when dialing an Emergency number from the handset.	Users must enter the Emergency Caller ID Number.
Messages Button Operation	Set the MESSAGE button function.	<ul style="list-style-type: none"> • Displays Message List • Call message Center
Visual On Call	Enable the phone visual ring indicator to light red for an active call.	<ul style="list-style-type: none"> • Enabled • Disabled
Ringtone Family	<p>Play different frequency and cadence variations of the ringtone. The default is Ringtone Family 1. Ringtone Family 2 through Family 4 uses the same default ringtone, but the pitch is different. Ringtone Family 5 uses different ring styles to differentiate between the call types on the phone (internal/external calls, calls from specific caller IDs, etc).</p> <p>NOTE: Allworx Server Administrator configures and controls the Allworx server settings.</p>	<ul style="list-style-type: none"> • Ringtone Family 1 • Ringtone Family 2 • Ringtone Family 3 • Ringtone Family 4 • Ringtone Family 5
Caller ID Preference	Controls the phone display.	<ul style="list-style-type: none"> • Caller ID • DNIS (the number the caller dialed)
Server Profile Select	Control the network settings used on the phone.	<ul style="list-style-type: none"> • User Server Selection • Ignore Server Selection

3. Press SELECT after making changes to the preferences.
4. Press the EXIT soft key twice. Press the YES soft key to save the changes or NO to cancel the changes.

6.3 Reboot the Phone

On occasion, it may be necessary to reboot the phone. For example, when the Allworx Server Administrator makes changes to the phone configuration.

Note:	Do not reboot the phone unless instructed to do so by the Allworx Server Administrator.
--------------	---

1. Press the CONFIG soft key. Use the UP / DOWN scroll soft keys to highlight the Reboot Phone option. Press SELECT .

If there are any unsaved changes, select the YES soft key to save any changes OR select NO to cancel changes made.

2. Select the YES soft key on the confirmation prompt to reboot.

6.4 Hot Desk Login

Hot Desking enables temporarily logging in to a shared phone. Then the system directs the calls to the shared phone and outgoing calls use the new caller ID. Users can initiate the login by selecting the Hot Desk Login option from the phone Config menu.

To manually Hot Desk into another phone:

1. Press the CONFIG soft key.
2. Use the UP / DOWN scroll soft keys to highlight the Hot Desk Login option. Press SELECT .
3. Enter the user extension and press the OK soft key
4. Enter PIN and press the OK soft key. The phone loads the new configuration.

6.5 Clear Call History

The Allworx phone retains the history up to 99 calls.

To clear the call history:

1. Press the CONFIG soft key.

2. Use the UP / DOWN scroll soft keys to highlight the Clear Call History option. Press SELECT .
3. Select the YES soft key to clear call history or NO to cancel the changes.

6.6 Refresh Directory

If new users or extensions have been set up on the Allworx server, the on-phone directory automatically updates after some delay.

To update the directory immediately:

1. Press the CONFIG soft key, and use the UP / DOWN scroll soft keys to highlight the Refresh Directory option. Press SELECT .
2. Press the EXIT soft key to exit the Refreshing the Directory screen.

6.7 Network Profiles

The phone stores Network Profiles, which are network and registration settings. Users can select a Network Profiles for use during different situations. Usage examples include connecting to a second Allworx server for disaster recovery purposes or temporarily connecting to the Allworx server from home. This avoids the need to manually change settings on the phone.

To change the Network Profile:

1. Press the CONFIG soft key.
2. Use the UP / DOWN scroll soft keys to highlight the Network Profiles option.
3. User the UP / DOWN scross soft keys to highlight the Network Profile to use. Press SELECT .
4. Press the EXIT soft key to exit the Refreshing the Directory screen.
5. Reboot the phone. See “Reboot the Phone ” on page 24 for more information.



7 Regulatory Notices

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. There is no guarantee, however, that interference will not occur in a particular installation. If this equipment causes harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and the receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

The booklet, “How to Identify and Resolve Radio-TV Interference Problems”, which the FCC prepares, may also be helpful.

Changes and Modification not expressly approved by the manufacturer or registrant of this equipment can void the authority to operate this equipment under Federal Communications Commission’s rules.

This product adheres to the IEEE 802.3af standard for Power over Ethernet (PoE).

This equipment is Hearing Aid Compatible (HAC).

This digital apparatus does not exceed the Class B limits for radio noise emissions from digital apparatus set out in the Radio Interference Regulations of the Canadian Department of Communications.

Le present appareil numerique n'emet pas de bruits radioelectriques dépassant les limites applicables aux appareils numeriques de la class B prescrites dans le Reglement sur le



brouillage radioelectrique edicte par le ministere des Communications du Canada.

Warning:	For use only with: A Power over Ethernet (PoE) supply – This product adheres to IEEE 802.3af standard for Power over Ethernet (PoE). OR: An Allworx-approved Limited Power Source, 24 VDC, 400 mA – The optional wall mount switching Power Supply has the following specifications: Input Voltage is 100-240VAC, 50/60Hz, 450mA. Output voltage is 24VDC @ 400mA. UL Listed Limited Power Source. Output connector size is 5.5 mm x 2.5 mm (inner diameter) x 9.5 mm with center positive. Do not connect an analog or ISDN phone line.
Caution:	The ear piece region on the handset can attract and retain small objects.

8 Abbreviations

Abbreviation	Definition
DND	Do Not Disturb
PBX	Private Branch Exchange
PoE	Power Over Ethernet
VoIP	Voice over Internet Protocol





Toll Free +1 866 ALLWORX • +1 585 421 3850

www.allworx.com

Revised: May 21, 2014